

Conversion Guide for 900 Series Wilkins Backflow

Check with local Authority Having Jurisdiction before performing field conversions.

* Please note that the 900 series backflow preventers are no longer in production, check with your manufactures representative for part availability.

	2-1/2" 950	2-1/2" 975	2-1/2" 950DA	2-1/2" 975DA
#1 Poppet	957-300	977-300	957DA-300	977-300
#2 Poppet	957-300	957-300	957DA-300	957DA-300
By-Pass Assy			957-540XL	977-540
Control Unit / Cover	957-3A-010F	977-CU	957-3A-010F	977-CU
Tag	T950	T975	T950DA	T975DA

	3" 950	3" 975	3" 950DA	3" 975DA
#1 Poppet	957-300	977-300	957DA-300	977-300
#2 Poppet	957-300	957-300	957DA-300	957DA-300
By-Pass Assy			957-540XL	977-540
Control Unit / Cover	957-3A-010F	977-CU	957-3A-010F	977-CU
Tag	T950	T975	T950DA	T975DA

	4" 950	4" 975	4" 950DA	4" 975DA
#1 Poppet	959-300	979-300	959DA-300	979-300
#2 Poppet	959-300	959-300	959-300	959DA-300
By-Pass Assy			959-540XL	979-540
Control Unit / Cover	957-3A-010F	977-CU	957-3A-010F	977-CU
Tag	T950	T975	T950DA	T975DA

	6" 950	6" 975	6" 950DA	6" 975DA
#1 Poppet	9510-300	9710-300	9510DA-300	9710-300
#1 Spring	9510-33	9710-33	9510DA-33	9710-33
#2 Poppet	9510-300	9510-300	9510-300	9510DA-300
#2 Spring	9510-33	9510-33	9510-33	9510DA-33
By-Pass Assembly			9510-540XL	9710-540
By-Pass BFP			34-950LXL	34-975L
Control Unit		977-CU		977-CU
Tag	T950	T975	T950DA	T975DA

	8" 950	8" 975	8" 950DA	8" 975DA
#1 Poppet	9511-300	9711-300	9511DA-300	9711-300
#1 Spring	9511-33	9711-33	9511DA-33	9711-33
#2 Poppet	9511-300	9511-300	9511-300	9511DA-300
#2 Spring	9511-33	9511-33	9511-33	9511DA-33
By-Pass Assembly			9511-540XL	9711-540
By-Pass BFP			34-950LXL	34-975L
Control Unit		9711-CU		9711-CU
Tag	T950	T975	T950DA	T975DA

	10" 950	10" 975	10" 950DA	10" 975DA
#1 Poppet	9512-300	9712-300	9512DA-300	9712-300
#2 Poppet	9512-300	9512-300	9512-300	9712DA-300
By-Pass Assy			9512-540XL	9712-540

Control Unit / Cover	9511-3A-010F	9711-CU	9511-3A-010F	9711-CU
Tag	T950	T975	T950DA	T975DA