

ALARM IS SHOWN TO BE INSTALLED ON OUTLET SIDE OF TANK

SINGLE TANKS (WITH BAFFLE) WILL HAVE ALARM INSTALLED ON THE INLET SIDE (BOTH INLET AND OUTLET INSTALLATION IS ALLOWED BUT GT RECOMMENDS INLET)

HAVE ALARM INSTALLED IN THE FIRST TANK OUTLET SIDE

PROJECT:

DRAWING NOT TO SCALE

DWG #: 21-5484-\$

REV. 3