




P6900-GEN Hydro-Generator Installation Instructions



How to install

Notes:

- 1.) **DO NOT USE ANY THREAD SEALING COMPOUNDS DURING INSTALLATION OF PRODUCT, DOING SO WILL VOID WARRANTY.**
- 2.) The P6900-GEN Hydro-Generator **MUST BE** installed between the faucet and the solenoid box.
- 3.) Specified for use with 1.5 GPM aerator only.

Procedure:

- Turn off water supply(s) before performing any work on the system.
- Disconnect the solenoid box from the faucet.
- Make sure both gaskets are placed and install the P6900-GEN between the faucet and solenoid box.
- Remove the battery box from the solenoid box.
- Remove sticker from the P6900-GEN connector. **IMPORTANT - Make sure the connector contacts do not touch any metal surfaces.**
- Install the P6900-GEN connector into the solenoid box battery port making sure it is oriented correctly and secure with screw provided.
- Turn on water, activate and allow 30 seconds continuous flow to purge air from the system.
- Verify there are no water leaks.

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

⚠ ADVERTENCIA: Cáncer y daño reproductivo - www.P65Warnings.ca.gov

⚠ AVERTISSEMENT: Cancer et effets néfastes sur la reproduction - www.P65Warnings.ca.gov