

**BLACK** RED (COMMON) (NORMALLY **GREEN CLOSED**) (NORMALLY 00 OPEN) 0 0 SmartP<u>ro</u> LCD DISPLAY OF SELECT PERSONS NEXT ANNOT TANK CONDITIONS **ALARM MONITOR INCLUDES AUDIBLE** AND VISUAL ALARM **POWER SUPPLY** -RJ-45 JACK 110V AC PLUG TANK#1 **RJ-11 JACK RJ-45 JACK** PLUG TRANSDUCER CABLE INTO TANK #1 RJ-45 JACK

> SKU 4630 INTERNAL PART #G4-4641

DWG. TITLE: SMARTPRO WIRELESS ALARM G4 INLET SIDE INSTALLATION

Proceptor\*



PROJECT:

SIZE DRAWING NOT TO SCALE

DWG #: 21-5529-S

REV. 0

1. TANKS INSTALLED IN SERIES (EX. GMC 2000(2)) WILL HAVE ALARM INSTALLED IN THE FIRST TANK OUTLET SIDE

SINGLE TANKS (WITH BAFFLE) WILL HAVE ALARM
INSTALLED ON THE INLET SIDE (BOTH INLET AND OUTLET
INSTALLATION IS ALLOWED BUT GT RECOMMENDS INLET)

ALARM IS SHOWN TO BE INSTALLED ON INLET SIDE OF TANK