

Model 600 Regulator Conversion Charts

1/2"	600	600LPV	600HLR	600HR
Bell Spring	62-33	62-33	601-33HR	601-33HR
Diaphragm	501-43	501-43	501-43	501-43
Teflon Diaphragm		62-43HT		
Plunger Spring		602-33LPVS	602-33LPVS	
Main Cap	601-3	601-3LP	601-3LP	601-3
Tag	T600	TLPV	TBL	THR

3/4"	600	600LPV	600HLR	600HR
Bell Spring	62-33	62-33	601-33HR	601-33HR
Diaphragm	501-43	501-43	501-43	501-43
Teflon Diaphragm		62-43HT		
Plunger Spring		602-33LPVS	602-33LPVS	
Stem	602-5	602-5LPV	602-5LPV	602-5
Stem Bolt	501B-9	503-11	503-11	501B-9
Tag	T600	TLPV	TBL	THR

1"	600	600LPV	600HLR	600HR
Bell Spring	603-33	603-33	503-33HR	503-33HR
Diaphragm	503-43	503-43	503-43	503-43
Teflon Diaphragm		503-43HT		
Plunger Spring		602-33LPVS	602-33LPVS	
Washer		204-14A	204-14A	
Adjustment Bolt	602A-11A	602A-11A	603A-11AHR	603A-11AHR
Bell Housing	603A-1-030F	603A-1-030F	603A-1-030F	603A-1HR-030F
Tag	T600	TLPV	TBL	THR

Model 600 Regulator Conversion Charts

1 1/4"	600	600LPV	600HLR	600HR
Bell Spring	604-33	604-33	1005-33	1005-33
Diaphragm	504-43	504-43	504-43	
Teflon Diaphragm		504-43HT		
Plunger Spring		604-33LPVS	604-33LPVS	
Spring Disc	602A-80	602A-80	604A-80	604A-80
Tag	T600	TLPV	TBL	THR

1 1/2"	600	600LPV	600HLR	600HR
Bell Spring	605-33B	605-33B	605-33HR	605-33HR
Diaphragm	505-43	505-43	505-43	505-43
Teflon Diaphragm		505-43HT		
Plunger Spring		605-33LPVS	605-33LPVS	
Spring Disc	505A-80	505A-80	604A-80	604A-80
Tag	T600	TLPV	TBL	THR

2"	600	600LPV	600HLR	600HR
Bell Spring	606-33	606-33	606-33HR	606-33HR
Diaphragm	606-43	606-43	606-43	606-43
Teflon Diaphragm		606-43HT		
Plunger Spring		606-33LPVS	606-33LPVS	
Tag	T600	TLPV	TBL	THR