


OIL OR GREASE POINT ALARM SYSTEM

WIRING DETAIL

SEE INSTRUCTION MANUAL FOR CALIBRATION PROCEDURE

OUTLET SIDE CONFIGURATION



TITLE: PROCEPTOR SEPARATOR OIL/GREASE POINT ALARM SYSTEM

PROJECT: WO:

REV	DATE	DRAWN
1	SEPT. 11, 2006	L. SIMKINS
2	SEPT. 19, 2006	V.H.
3	NOV. 19, 2010	F.H.
4	DEC. 15, 2010	F.H.
5		
6		
7		
8		
9		
10		
DRAWN BY: L. SIMKINS		
DRAWN DATE 26/6/6		

Proceptor
by Greenturtle

877-428-8187 USA
877-966-9444 CAN
www.greenturtletech.com

SIZE DWG. NO.	REV.
A	4
ALARM-MC (OUTLET)	
SCALE: NTS	AUTOATTR

IN PROCEPTOR OMC OR GMC SEPARATOR MULTIPLE TANK SYSTEMS THE ALARM IS USUALLY MOUNTED IN MANWAY OF THE FIRST TANK IN SERIES