

RELIEF VALVE - 2 ½" to 10"

Models 375, 375A, 375AST, 475 and 475V



Repair Kit Components		2 ½" - 6"					8" and 10"			
Item #	Item Description	RK212-375	RK212-375R	RK212-375RVCI	RK212-RV-COVER	RK212-RV-PLUNGER	RK8-375	RK8-375R	RK8-375RVCI	RK8-RV-COVER
1	Bolt, Cover				● (x6)					● (x6)
2	Cover				●					●
3	O-Ring, Upper Plunger	●	●	●			●	●	●	
4	Upper Plunger			●		●			●	
5	Diaphragm	●	●	●			●	●	●	
6	Lower Plunger			●		●			●	
7	Seal Ring	●	●	●			●	●	●	
8	Seal Retainer			●					●	
9	Washer			●					●	
10	Bolt			●					●	
11	Relief Valve Spring	●		●			●		●	
12	Relief Valve Seat			●					●	
13	O-Ring, Relief Valve Seat	●	●	●		●	●	●	●	
14	O-Ring, Relief Valve	●	●	●			●	●	●	
	Sensing Tube Fitting				●					●

Item No.	Repair Kit Description
2 ½" - 6"	
RK212-375	Complete Relief Valve Repair Kit, 2 ½" - 6"
RK212-375R	Relief Valve Rubber Repair Kit, 2 ½" - 6"
RK212-375RVCI	Relief Valve Complete Internals Repair Kit, 2 ½" - 6"
RK212-RV-COVER	Relief Valve Cover Repair Kit 2 ½" - 6"
RK212-RV-PLUNGER	Relief Valve Plunger Repair Kit 2 ½" - 6"
8" and 10"	
RK8-375	Complete Relief Valve Repair Kit, 8" and 10"
RK8-375R	Relief Valve Rubber Repair Kit, 8" and 10"
RK8-375RVCI	Relief Valve Complete Internals Repair Kit, 8" and 10"
RK8-RV-COVER	Relief Valve Cover Repair Kit 8" and 10"

RELIEF VALVE - 2 1/2" to 10"

Models 375, 375A, 375AST, 475 and 475V

Parts Drawing

